


Operating Instruction



- It can be used in most brands of the world.
It can control most brands of devices that are commonly used in the world.
Easy programming by auto-search or manual search.



5-in-1 Universal Remote Control

Catalogue English

Code form for the components

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.


Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

5-in-1 Universal Remote Control

An introduction to the product

This remote control is a new type of universal remote control which has powerful built-in code database and through the simple setting of this unit, it can be used to easily control various electric appliances including TV/TEXT, DVD, SAT (CABLE), etc. This unit has power failure memory function and it requires no resetting after the replacement of batteries. The operation is simple and it is an ideal choice for the combined use of remote controls for various electric appliances and the substitution of the lost and damaged remote controls.

Description of control panel




Comparison table of TV, VCR, DVD and SAT keys with functions

Comparison table of TV, VCR, DVD and SAT keys with functions, showing key symbols and their corresponding functions for each device type.

Installation of battery

Open battery lid, and input 2 new AA batteries (# 5) (non giveaway) according to the "+" marks in the battery cell per the drawing:



- Remarks:
This remote control can only be used when your electric appliances have the receiving functions and receiving system.
Do not mix the new batteries with the used batteries or different models of batteries for the same remote control.
In case of fluid leakage for any batteries, the batteries must be removed and the battery chamber must be cleaned before replacing the new batteries.
Please remove the batteries if the remote control is not in use for a long time.

Setting of the remote control

This remote control has two setting methods (Type A and Type B). Please select the type for operation

Table showing Range of codes for TV (1000-1981) and VCR (2000-2301) for SAT/CBL (3000-3773) and DVD (4000-4285).

A. Code input method

Manually switch on the electric appliances which you wish to control by remote and search from the code table for the brand names for the electric appliances you want to control. Set from the first group of codes for the brand and repeat the procedures of 2-6 until the codes for your electric appliances have been found. In case all the codes cannot properly make your remote control work (or the brand names of your electric appliances are not included in the code table), please use Type B method for setting.

- 1. Manually switch on the electric appliances which you wish to control by remote and search from the code table for the brand names for the electric appliances you want to control.
2. Press "TV" key once, and the indicator lights on.
3. Press "TV" key once, and the indicator lights on.
4. Press "TV" key once, and the indicator lights on.




Table of SETUP CODES FOR DVD with columns for brand and code.

Table of SETUP CODES FOR SAT CABLE with columns for brand and code.

Table of SETUP CODES FOR VCR with columns for brand and code.

Table of SETUP CODES FOR VCR with columns for brand and code.

Table of SETUP CODES FOR TV with columns for brand and code.

Table of SETUP CODES FOR TV with columns for brand and code.

Table of SETUP CODES FOR TV with columns for brand and code.

Table of SETUP CODES FOR VCR with columns for brand and code.

B. Automatic code searching method

- 1. Manually switch on the electric appliance that you wish to control and aim the remote control at the electric appliance light will be switched on. For example, the TV.
2. Press "TV" key, till the indicator turns on (Note: When any of the Electric Appliance Selection Buttons is pressed, the signal light will be dimmed once, and then it will be switched on again)
3. Press "TV" key, till the indicator turns on.

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

Technical parameters

Control Distance: Approximately 8 metres, depending on the home electric appliances
Battery Life: Approximately 12 months

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV

SETUP CODES FOR TV