



IMPORTANT SAFETY INSTRUCTIONS AND PRECAUTIONS

- Read all instructions carefully before use.
- Retain manuals for future reference.
- Use this product only in the manner described.
- Only use a water-dampened soft-cloth to clean the surface of this product.
- Only place this device on stable surfaces and ensure that any attached cables are secure and will not cause the device to fall.
- There are no user serviceable parts in this product.
- Un-authorized attempts to dismantle or repair this product will void product warranty

PACKAGE INCLUDES

1 x Soundbar, 1 x Wireless Subwoofer, 1 x Optical Cable, 1 x 3.5mm Audio Jack to RCA Cable, 1 x Subwoofer Cable, 1 x Remote Control, 2 x Mains Power Adapter, 1 x Quick User Manual.

THE REMOTE CONTROL





1	ON / OFF	Turn Sound Bar On or Off
2	MUTE	Mute or Unmute audio
3	BASS-	Reduce Bass sound
4	BASS+	Increase Bass sound
5	TREBLE-	Reduce Treble sound
6	TREBLE+	Increase Treble sound
7	VOL +	Increase Volume
8	CH -	Previous music file / Radio station
9	PLAY/PAUSE	Pause or Play Audio while playing
10	CH +	Next music file / Radio station
11	VOL -	Decrease Volume
12	FM	Select Audio Input via FM Radio
13	BLUETOOTH	Select Audio Input via BLUETOOTH
14	LINE IN	Select Audio Input via LINE IN
15	USB	Select Audio Input via USB
16	OPTICAL	Select Audio Input via OPTICAL INPUT

REPLACING THE BATTERIES

- 1. Open the battery compartment by sliding the cover back.
- 2. Insert the new battery as pictured making sure you have observed the correct polarity.
- 3. Close the battery compartment.

Note: the remote control has a usable angle of 30 degrees from the speaker IR receiver.



ON DEVICE CONTROLS and INPUTS



1	POWER	Turn Soundbar and Sub On or Off
2	SOURCE	Toggle between audio input sources
3	VOL+ /NEXT	Increase volume OR select next song (or radio station)
4	VOL-/PREV	Decrease volume OR select previous song (or radio station)
5	LINE IN	Connect any audio device via a 3.5mm headphone audio socket
6	USB IN	Connect your thumb drive via the USB socket

ON DEVICE DISPLAY for INPUTS



On device display (See table below)

1	LINE	Select LINE IN Audio Input
2	FM	Select FM RADIO Audio input
3	USB	Select USB Audio input
4	BLUE	Select BLUETOOTH Audio input
5	OPT	Select Optical Audio input

CONNECTING YOUR SPEAKER TO YOUR TV
GOOD



You can connect your soundbar to your TV if you have a headphone / Aux 3.5mm jack.

BEST






If your TV has an Optical port, you can connect the soundbar to your TV this way for digital sound.

CONNECTING YOUR WIRELESS SUBWOOFER

The external Subwoofer needs no special connection technique. Simply turn the Subwoofer on while the Soundbar is turned on and it will start automatically.

Note: Your Subwoofer also has an additional wired Subwoofer input, should you wish to not use a Wi-fi connection. (Cable included.)





CONNECTING A DVD OR BLU-RAY PLAYER

If your DVD or BLU-RAY player has the Red and White audio output port, please use the supplied Red and White RCA cable to connect the soundbar to your player.

CONNECTION VIA BLUETOOTH

Please select Bluetooth mode on your soundbar and smartphone and search for SPK-SB140SUB. Then pair and connect.



BLUETOOTH CONNECTION (EXTENDED VERSION)

- 1) Press the SOURCE button to toggle to BT function. “BLUE” will begin to flash on screen, which means the Bluetooth “pairing mode” has been activated.
- 2) Turn the Bluetooth function on, on your device (smart phone or tablet etc.).
- 3) Scan for new devices, and look for SPK-SB140SUB to pop up on screen.
- 4) Once found and selected, you may be prompted for a password to complete the pairing process. **The password is 0000 (4 zeros).**
- 5) Once connected and paired, “BLUE” will stop flashing on the soundbar which indicates that pairing has been completed.
- 6) You are now ready to listen to music wireless via your sound bar. Open your music files, select a song and press play.

CONNECION TYPES EXPLAINED

Connection type	Connection Method	Via on-board buttons	Via Remote Control
LINE IN	Via 3.5mm Audio Cable	Connect your audio device to the sound-bar using the 3.5mm cable and press the SOURCE button until the word LINE is shown on front display.	Connect your audio device to the sound-bar using the 3.5mm cable and press the LINE button until the word LINE is displayed.
USB (Storage)	Music playback Via USB Storage	Connect your storage device (<i>such as a thumb drive</i>) to the sound-bar and press the SOURCE button until the word USB is shown on the front display.	Connect your storage device (<i>such as a thumb drive</i>) to the sound-bar and press the USB button. The word USB will be shown on the front display.
BLUE	Via Bluetooth (Wireless)	Press the SOURCE button until the word BLUE is shown on the front display. Turn on your portable Bluetooth device and follow the pairing instructions above.	Press the BLUE button until the word BLUE is shown on the front display. Turn on your portable Bluetooth device and follow the pairing instructions above.
OPT	Via Optical fibre Cable	Connect your Media device (<i>such as Blu-ray or DVD player</i>) to the sound-bar using an Optical Fibre Cable and press the SOURCE button until the word OPT is shown on the front display.	Connect your Media device (<i>such as Blu-ray or DVD player</i>) to the sound-bar using an Optical Fibre Cable and press the OPT button. The word will be shown on the front display.
FM (Radio)	Listen to FM Radio	Press the SOURCE button until the word FN (meaning FM) is shown on the front display.	Press the FM button. The word FN (meaning FM) will be shown on the front display.

FAQ

Problem	Solution
No sound	Make sure the AC adapter is plugged into a working outlet and check all cable are mounted securely.
Distorted sound	Check your source device to see if it is causing the distortion. Set the device and soundbar volume to a lower level
Unbalanced sound	If the volume remains low even when the soundbar’s volume is turned all the way up, check the source device to make sure it is connected via variable output. Make sure the output is not turned down too low.

SPECIFICATIONS

Output Power	140 Watt (PMPO)
Speaker size	Sound bar: 5W RMS, 4 x 2inch, 80-16khz Subwoofer: 10W RMS, 1 x 5inch, 60-20khz
Number of speakers	2 (1 x Soundbar, 1 x Subwoofer)
Passive Radiator	1 (built into soundbar)
Soundbar material	ABS Plastic (Crack resistant)
Dimensions	750l x 58w x 60h (Soundbar) 19.7l x 19.7w x 28h (Subwoofer)

Warranty Against Defects

Laser Corporation Pty Ltd (“Laser”) warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (within Dead on Arrival period) for this product if it becomes defective within the warranty period.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect. Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or fund the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on “Consumers (End Users)”). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Step 5: For further details on warranty cover and returns, please check [Terms and Conditions for Warranty Returns](#) section on <http://www.laserco.com.au/warranty>

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



NAVIG[8]R

PRECISION
gaming accessories

CONNECT

naum8
GPS ESSENTIALS

iRange!
by LASER

